

Q-FOCUSER-LUNT-CRAYFORD / Q-FOCUSER-LUNT-RP INSTALLATION INSTRUCTIONS

Installation of the Q-Focuser-Lunt-Crayford and Q-Focuser-Lunt-RP is straightforward and requires only a few simple steps.

Tools needed: small diameter Philips head screwdriver, 2.0mm hex key, 1.5mm hex key (not provided).

1. Remove the fine and coarse focus knobs from the Lunt focuser.
- 2a. **Standard Version** - Slide the provided 3D printed coupler onto the brass focuser pinion shaft. Match the flat on the coupler with the flat on the pinion shaft and secure with two set screws, using the 1.5mm hex key. Do not over tighten the screws.
- 2b. **High Precision Version** – Using the appropriate coupler provided with the Q-Focuser, slide the coupler onto the focuser fine focus pinion shaft. Temporarily place the bracket onto the silver body of the focuser. Estimate where the outermost clamping screw will be visible through the side access hole of the bracket, closest to the Q-Focuser. Remove the bracket, and keeping the coupler in the same position, clamp the coupler onto the focuser fine focus pinion shaft using the 2.0mm hex key.
3. Slide the bracket onto the silver body of the focuser until the focuser hits the stop on the inside of the bracket. Rotate the bracket to the desired position and tighten the two Philips head screws to clamp the bracket onto the focuser.
- 4a. **Standard Version** - Slide the Q-Focuser pinion into the coupler. Note that there is a flat on the coupler hole that matches the flat on the Q-Focuser pinion. Once the Q-Focuser pinion is inside the coupler, rotate the Q-Focuser until the set screws in the coupler are visible through the side access holes in the bracket. Secure the coupler to the Q-Focuser pinion with set screws. Do not over tighten the screws. Attach the Q-Focuser to the bracket using the supplied M3x20mm screws.
- 4b. **High Precision Version** – Slide the Q-Focuser pinion into the coupler. Secure the Q-Focuser to the bracket using the supplied M3x20mm screws. Using the 2.0mm hex key, tighten the coupler onto the Q-Focuser pinion through the access hole closest to the Q-Focuser.

Please inform of any additions or corrections to these directions by sending an email to buckeyestargazer@gmail.com